Rev. A1



#### 1. **SCOPE**

This instruction sheet is to provide useful information for correct assembly of the harness and correct assembly / disassembly of the connector.

### 2. Part number and Description

| Part Number | Description                       | Pin |
|-------------|-----------------------------------|-----|
| 85202       | JPT Plug Assy Standard            | 2   |
| 368354      | JPT Plug Assy Standard with Clip  | 2   |
| 368412      | JPT Plug Assy                     | 2   |
| 936567      | JPT Plug Assy                     | 2   |
| 85205       | JPT Plug Assy Standard            | 3   |
| 368215      | JPT Plug Assy Knock Sensor        | 3   |
| 368356      | JPT Plug Assy Standard with Clip  | 3   |
| 85196       | JPT Plug Assy Reverse             | 3   |
| 936136      | JPT Plug Assy Injector with Clip  | 3   |
| 368000      | JPT Plug Assy Multi/CPS           | 3   |
| 936304      | JPT Plug Assy Standard with Short | 3   |
| 368491      | JPT Plug Assy                     | 3   |
| 368492      | JPT Plug Assy                     | 3   |
| 85168       | JPT Plug Assy Standard            | 4   |
| 368126      | JPT Plug Assy Reverse             | 4   |


Note Part number is consisted from listed base number and 1 digit numeric prefix and suffix with dash. When prefix zero, zero and dash are omitted.

#### 3. **Reference Document**

- 3.1 Refer to customer drawing for specific part numbers for each base number.
- 3.2 Application spec.: 114-18050




# 4. Delivery Condition



# 5. Contacts Loading

Insert the contacts into the housings cavities according to Figure 2 until the lance on the metal contacts body is released.





### 6. Spacer locking


After the insertion of the contacts into their cavities, lock the spacer, by pushing in the direction show by the arrows on Figure 3 below, into the relevant seats in the male and female housings until the end position.



### 7. Mating Female and Male Connectors

To mate a female connector onto a male connector or male socket, proceed as shown Figure 5. Push together until they click into place. Never press the spring to obtain the mating, this prevents the proper locking of the connectors and can also prevent the assembly from being sealed.

Check proper locking by pulling on the connectors without pressing on the locking spring.








411-61006

# 8. Unmating Female Connectors

To unmate female connector, press on the locking spring while pulling on the connector.





# **Product Specification**

411-61006

# 9. Revision History

| A1   | RELEASED        | 15.Nov.′11 |
|------|-----------------|------------|
| REV. | REVISION RECORD | DATE       |

# 10. Specification Approval

Prepared by, Checked By,

K.T. JUNG K.T. LIM

Product Engineer Senior Product Engineer

Approved by,

H.G. CHO

Product Engineering Manager

Loc. DS Rev. A1 Page 5 of 5