



# 'Quick-Start' Programming and Calibration Guide

## MP-2000 Dual Channel LVDT/RVDT Readout/Controller



This 'Quick-Start' Guide provides the minimal steps and instructions for getting your MP-2000 up and running in the single and dual channel modes. To understand and access the full features and capabilities of the MP-2000, download the Operation Manual from our web site

**Step 1.** Wire the LVDT/RVDT transducer(s) to the supplied connector plugs for J1/J2. Refer to the Operation Manual (Wiring Instructions) for details.

**CAUTION** Do NOT connect the transducers to the MP-2000 at this time!

**Step 2.** Determine the full scale output voltage of the LVDT/RVDT, at the preferred operating frequency, for both 1 and 3 VRMS excitation voltages. The full scale output voltage may be obtained from the individual LVDT/RVDT data sheet, or can be calculated as follows:

LVDT/RVDT sensitivity (in V/V/inch or V/V/degree), multiplied by the excitation voltage (OSC 1 or 3 VRMS), multiplied by the displacement of the LVDT in inches, or RVDT in degrees, from the electrical zero (also called Null Position or mid-stroke).

**CAUTION** For 3V, ensure VDT input impedance is high enough to avoid damage!

As an example, the calculation for an HR 1000 LVDT, ±1 inch range (1 inch full scale), with a sensitivity of 0.39V/V/inch at 2.5KHZ, with 3 VRMS excitation would be done as follows:

$$0.39 \times 3 \times 1 = 1.17 \text{ VRMS full scale output}$$

*Note: If using both channels and the transducers are different, you will need to do this for each channel!*

**Step 3.** Using the information from Step 2 above, determine and note the proper gain setting for each channel. Full scale outputs of 0.36 to 0.57 VRMS require HIGH GAIN, while outputs of 0.72 to 1.14 VRMS require LOW GAIN.

**Step 4.** Connect the power supply to J5 (Power) on the rear panel. The MP-2000 will take approximately 20 seconds to boot up, and will display:



**Step 5.** After booting for the first time, the top level menu appears:



*Note: If the MP-2000 was previously programmed, it will instead go directly into the RUN mode, and pressing [MENU] will go to the top level menu.*

**Step 6.** In the above top level menu, press [▼] to select the PROGRAM SETTINGS and then press [ENTER]. The system will ask for the password to go into PROGRAM mode. The password is [▲] [▼] [▶] [▼] (successively press these buttons). The following PROGRAM SETTINGS menu will appear:




*Notes:*

- If the password is entered incorrectly, the system will ask for the password again. After four incorrect attempts, the system will exit and return to the top level menu.

- Use [▲] [▼] [▶] to navigate the menu and to make changes to values within the submenus.
- Pressing [ENTER] will enter the menu of the selected item, except in the lowest menu levels where pressing [ENTER] will perform the same task as [▲] [▼] [▶] or [MENU], which is returning back to the previous menu.

**Step 7.** Press [ENTER] to program Channel A. The following submenu will appear:



Set the following parameters:

- DECIMAL POINT for position readings.
- CALIBRATION VALUE, the distance you will move the LVDT core, or angle you will rotate the RVDT shaft from the electrical zero during the calibration.
- FULL SCALE, the displacement from zero for which the transducer is rated.
- GAIN setting from Step 3 for Channel A.

When done, press [MENU] to return to the PROGRAM SETTINGS menu. If you are using two transducers, select CH(B) SETTING, and set the parameters above again for Channel B.

**Step 8.** Return to the PROGRAM SETTINGS menu, and select OSC CHOICE. The below submenu will appear:




**Step 9.** In the OSC SOURCE submenu, select OSC INTERNAL. The required frequency is determined by the specific LVDT/RVDT used. This setting is common to both channels. The required oscillator voltage for each channel was determined in Steps 2 and 3 above. Enter appropriate values.

**CAUTION** For 3V, ensure VDT input impedance is high enough to avoid damage!

**Step 10.** Return to the PROGRAM SETTINGS menu. Select CALIBRATION SWITCH and then select ENABLE in the submenu.

**Step 11.** Press [MENU] repeatedly until you exit fully out passed the top level menu. The 'RUN' screen will appear displaying both channels:




**Step 12.** When using an LVDT, place the core inside the bore. Connect the transducer(s) to J1 (Channel 1) and J2 (Channel 2) on the rear panel.

**Step 13.** Press the A/B [ENTER] button, and the screen will toggle to display Channel A only. Press [▼] and [ENTER] simultaneously, and the MP-2000 will enter the 'Voltmeter' mode as shown below:



**Step 14.** Move the core (LVDT) or rotate the shaft (RVDT) until you obtain the closest reading to 0V. This is the zero or null (MIDDLE POINT) position. Press [MENU] to return to the RUN screen.

**Step 15.** Press the CAL [▼] button and the following screen will appear:



As you are already at the null (MIDDLE POINT), press [ENTER], and following screen will appear:



**Step 16.** Displace to the exact distance (in the positive direction) that was entered as the Calibration Value in Step 7, then press [ENTER]. The following screen will appear:



Press any key to exit. The calibration process of Channel A is complete. Repeat Steps 12 through 15 to calibrate Channel B if you are using two transducers (use A/B [ENTER] button to toggle)

**Your MP-2000 is now ready for use!**

Measurement Specialties, Inc., a TE Connectivity company.

Measurement Specialties (MEAS), American Sensor Technologies (AST), TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2016 TE Connectivity Ltd. family of companies All Rights Reserved.