



FEATURES

- Signal Conditioned Vibration Sensor
- High Pass Filter @ 1.3Hz
- Low Pass Filter @ 177Hz
- On Board 3.3 V Battery or User Power Supply
- Both Analog and Digital Output

APPLICATIONS

- Wake-up Sensor
- Drop Detection Sensor
- Flow Sensor
- Activity Sensor
- Alarm Trigger

MINISENSE 100 ANALOG PCB

SPECIFICATIONS

- Evaluation Circuit for Vibration Sensor
- Low Power Battery Powered
- LED for Trigger
- High Sensitivity
- Analog and Digital Signal Access Points

The LDTC MiniSense 100 Analog PCB provides a simple way to evaluate the LDTC MiniSense 100. The unit consists of LDTC MiniSense 100, a low-power operation amplifier, comparator, and DC/DC converter, and the passive components used for signal conditioning. The sensor and circuit are assembled on a double-sided PCB with test points, ON/OFF switch, and 0.100" plated through holes for easy user interface. The PCB has adjustable gain and demonstrates the basic capabilities of LDTC MiniSense 100 vibration sensor.

SPECIFICATIONS

CHARACTERISTIC (T=25(C))	SYMBOL	MIN	TYP	MAX	UNITS
Lower Frequency	f _{L3dB}	-	1.3	-	Hz
Limit (-3dB Point) High Frequency	f _{U3dB}	-	177	-	Hz
Limit (-3dB Point) External Supply Voltage	+V	0.9	3.3	5.5	VDC
Supply Current	Isupply	-	2.8	-	mA

PIN DESCRIPTIONS


PIN NUMBER	NAME	DESCRIPTION
1	VDD	Connect to Power Supply
2	Α	Analog Signal output
3	D	Digital Signal output
4	GND	Connect to GND

^{**}Note: when switch set to "OFF", PCB uses external power if applied to (+) & (-) input pins**


ENVIRONMENTAL CHARACTERISTICS

CHARACTERISTICS	SYMBOL	MIN	TYP	MAX	UNITS
Operating Temperature	TOP	-20	-	+85	ōC
Storage Temperature	TS	-40	-	+105	ōC
Relative Humidity	RH	0	-	90	%R.H

ELECTRICAL SCHEMATIC



ELECTRICAL PCB REFERENCE




ELECTRICAL PCB DESCRIPTION


The impedance matching resistor, R5, in parallel with the 240pF sensor capacitance, establishes the high pass input filter at approximately 1.3Hz (f=1/2 π RC). After impedance buffering the LDTC signal is DC coupled to a gain stage through a 0.7Hz high pass filter formed by C10 and R10. The amplifier gain is set by R9, R6, and the R8 potentiometer in the OP-amp's feedback loop: Gain=1+ [R9/(R8+R6)] with a max gain of 20dB, min gain of 6dB. C6 in parallel with R9 in the feedback loop form a low pass filter with a corner frequency of 177Hz.

After signal conditioning the analog voltage is buffered for output and also fed into a comparator. R15 & R4 set the threshold voltage. If the amplified signal exceeds the threshold voltage, the comparator output will be pulled low through a 4.7K resistor and the PNP transistor will turn on the LED. The reference voltage, VREF, is 1.65V, or half of the internal 3.3V rail. The on board 3.3V battery and external power are converted to a 5V supply using a DC-DC converter.

FREQUENCY RESPONSE



MiniSense 100 vibration sensor Analog PCB Acceleration Response



ORDERING INFORMATION

Description

Part Number

MiniSense 100 Analog PCB

1007215

NORTH AMERICA

Measurement Specialties, Inc., a TE Connectivity Company 1000 Lucas Way Hampton, VA 23666 Sales and Customer Service Tel: +1-800-745-8008 or +1-757-766-1500 Fax: +1-757-766-4297 Technical Support Email: piezo@meas-spec.com

EUROPE

MEAS Deutschland GmbH a TE Connectivity Company Hauert 13 44227 Dortmund Germany Sales and Customer Service Tel: +49 (0)231 9740 21 Technical Support Tel: +49 (0)6074 862822 Email: piezoeurope@meas-spec.com

ASIA

Measurement Specialties (China), Ltd., a TE Connectivity Company F1.6-4D, Tian An Development Compound ShenZhen, China 518048 Sales and Customer Service Tel: +86 755 8330 1004 Technical Support Email: piezo@meas-spec.com

TE.com/sensorsolutions

Measurement Specialties, Inc., a TE Connectivity company.

Measurement Specialties, TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2015 TE Connectivity Ltd. family of companies All Rights Reserved.