



JST Male Pin Figure 1

**YAZAKI Female Receptacle** 

#### **1. INTRODUCTION**

This instruction sheet covers assembly (inserting terminals into the connectors and mating the connectors) and disassembly (unmating the connectors and extracting the terminals from the connectors) procedures for 6-position 0.64mm sealed inline connectors shown in Figure 1.

Cap Assembly

These connectors accept the terminals listed in Figure 1. An optional wire dress cover is available for the cap assembly to protect the termination point of the wires to the contacts.



Dimensions in this instruction sheet are in millimeters [with inches in brackets]. Figures are not drawn to scale.

#### 2. DESCRIPTION

Each connector features a housing (with circuit cavities), a matte seal (located in front of the cavities), matte seal cover, TPA, and a key or key slot. In addition, the plug assembly features a ring seal and is available with or without a CPA; and the cap assembly features a retainer. The retainer secures the optional wire dress cover. Refer to Figure 1.

Each row of cavities is marked on the wire end of the connector for circuit identification. The cavities are

JST is a trademark of Nippon Acchakutanshi Seizo Kabushiki Kaisha. Yazaki is a trademark of Yazaki Corporation.

©2010 Tyco Electronics Corporation, Berwyn, PA All Rights Reserved

TOOLING ASSISTANCE CENTER 1-800-722-1111 PRODUCT INFORMATION 1-800-522-6752

This controlled document is subject to change. For latest revision and Regional Customer Service, visit our website at www.tycoelectronics.com

1 of 8 LOC B

TE logo and Tyco Electronics are trademarks.

\*Trademark. Other products names, logos, or company names might be trademarks of their respective owners.

#### 4. REVISION SUMMARY

Initial release of instruction sheet

polarized to prevent the terminals from being inserted upside-down. When inserted, the terminal deflects a retention finger, locking the terminal into place. After all terminals are inserted, the TPA is used to ensure that the terminals are fully seated and to provide additional terminal retention. If a terminal is not fully seated, the TPA will not move.

7116-4618-02

SAITW-A03T-064

Each connector is shipped with the TPA in the pre-set position. The TPA is actuated when moved to the fully engaged position.

When mating connectors, the key and key slot are used to align the mating connectors. The CPA (if present) is used to ensure that the connectors are fully engaged.

### 3. ASSEMBLY

Before starting assembly, ensure the following:

- all terminals are properly crimped (consult terminal manufacturer)
- connector TPA is in the pre-set position before inserting any terminals into the circuit cavities

 plug assembly CPA (if present) is in the pre-set position before mating the connectors

## **Inserting Terminals into Plug Assembly**



### **Inserting Terminals into Cap Assembly**



# Mating Connectors



# **Unmating Connectors**







## **Extracting Terminals from Plug Assembly**



### 2 **Optional Wire Dress Cover** Must Be Removed Pull TPA Out of Housing Insert Pull Tip of Tool in **TPA Disengaging Tool** Center Cutout (Customer-Supplied, Refer to Figure 2 of TPA for Design Recommendation) Important: Make sure to orient tip of tool as shown. Δ 3 Rotate Tool to Release Retention Finger **Extraction Tool** Push and Simultaneously Terminals in Upper Cavity 3-1579007-6 Rotate Pull Wire Tool Insert ñ. Terminals in Lower Cavity Insert Tip of Tool into Cavity of Terminal to Be Removed Note: Place Tip of Tool Above Terminal in Upper Cavity Below Terminal in Lower Cavity Tip Must Be Between Terminal and Plug Retention Finger Push and as Shown in Step 4 Rotate Important: Make sure to orient tip of tool as shown Simultaneously Tool

# **Extracting Terminals from Cap Assembly**

in Step 4.

Pull Wire



Recommended Design for TPA Disengaging Tool for Cap Assembly



Figure 2