




- ① Select two housings and remove the tabs and the nuts, as shown.

NOTE



Be sure that the label (shown on each housing) is positioned as indicated before removing tabs.



- ② Assemble the connectors and insert them into back of housings according to Instruction Sheet 408-3199, which is packaged with the housings.

Install the double-gang faceplate with the two (2) screws provided.

Faceplate Assembly
555670-1

REVISION SUMMARY

- Updated document to corporate requirements
- New logo