





A-MP*23 POSITION SERIES "G" MODULES FOR A-MP TYPE II, III & III PLUS AND SUBMINIATURE COAXICON* CONTACTS





1. These instructions cover the Series "G" Modules shown in the illustration and selection and crimping of Contacts for use in the Modules. These Modules are used in A-MP Series "G" Connectors. To assemble Modules in Connectors refer to AMP Instruction Sheet No. 7184 which is packaged with the Connectors.

2. CONTACT SELECTION & CRIMPING

- (a) To select the proper Contact for the size of Wire you have, refer to AMP Instruction Sheet No. 1379.
- (b) Crimp these Contacts using the A-MP Crimping Tools referenced on IS-1379.

3. CONTACT INSERTION

NOTE: Use Pin Contacts only in Male Module; use Socket Contacts only in Female Module.

- (a) Push Contact all the way into the Module. Pull back lightly on Wire to make sure Contact is completely inserted.
- (b) To insert Contacts crimped to small, flexible Wire, use A-MP Insertion Tool No. 91002-\(\sigma\).

4. CONTACT EXTRACTION

To remove Contacts from Module, use A-MP Extraction Tool No. 305183. See AMP Instruction Sheet No. 1216 which is packaged with the $T\infty l$.