

INSTRUCTIONS FOR TRUBLUE FIRMWARE UPDATE

UPDATING THE TRUBLUE DATALOGGER FIRMWARE CAN BE COMPLETED BY FOLLOWING THE INSTRUCTIONS BELOW. IT IS RECOMMENDED TO CHECK FOR UPDATES EVERY SIX (6) MONTHS, TO MAINTAIN THE INSTRUMENT PERFORMING AT OPTIMUM LEVELS.

- **1.** Go to site http://www.meas-spec.com/water-level-sensors/water-level-temperature-pressure/trublue-data-loggers.aspx
- 2. Select your model datalogger link.
- **3.** Under the literature tab select "TruBlue Firmware for...." Link, and when prompted select "Save".
- **4.** Move *.zip file from the Downloads folder to the TruBlue folder in My Documents when TruWare was installed.
- **5.** Extract the *.hex file from the *.zip.
- **6.** Connect your TruBlue datalogger to the PC using either of the communication cables available.
- 7. Open TruWare making sure it sees the connected the datalogger.

- 9. Select check box adjacent to the transducer serial number.
- **10.** Select the downloaded firmware by selecting the "Browse" box and navigating to the "TruBlue" folder from the Open File Dialog window.
- **11.** Select the "Upgrade" button to begin the upgrade.

NORTH AMERICA

Measurement Specialties, Inc., a TE Connectivity Company 1000 Lucas Way Hampton, VA 23666 United States Phone: +1-800-745-8008

Fax: +1-757-766-4297 Email: WL.Sales@te.com

EUROPE

MEAS Deutschland GmbH a TE Connectivity Company Hauert 13 D-44227 Dortmund Germany Phone: +49-(0)231-9740-0 Fax: +49-(0)231-9740-20 Email: customercare.dtmd@te.com

ASIA

Measurement Specialties China Ltd., a TE Connectivity Company No. 26, Langshan Road High-tech Park (North) Nanshan District, Shenzhen 518057 China Phone: +86-755-33305088

Phone: +86-755-33305088 Fax: +86-755-33305099 Email: customercare.shzn@te.com

te.com/sensorsolutions

Measurement Specialties, Inc., a TE Connectivity company.

Measurement Specialties (MEAS), American Sensor Technologies (AST), TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2016 TE Connectivity Ltd. family of companies All Rights Reserved.