User Guide

WINTOTAL QUICK START GUIDE - WINTOTAL-7-END-USER-LICENSE PICTOGRAM

THIS IS A CLASS 1 DOCUMENT WHICH IS NONCONFIDENTIAL.

The information contained within this document is the property of TE Connectivity. It is supplied in confidence and the commercial security of the contents must be maintained. It must not be used for any purpose other than that for which it is supplied nor may any information contained in it be disclosed to unauthorised persons. It must not be reproduced in whole or in part without obtaining written permission from TE Connectivity (TE).

While TE has made every reasonable effort to ensure the accuracy of the information in this catalog, TE does not guarantee that it is error-free, nor does TE make any other representation, warranty or guarantee that the information is accurate, correct, reliable or current. TE reserves the right to make any adjustments to the information contained herein at any time without notice. TE expressly disclaims all implied warranties regarding the information contained herein, including, but not limited to, any implied warranties of merchantability or fitness for a particular purpose. The dimensions in this catalog are for reference purposes only and are subject to change without notice. Specifications are subject to change without notice. Consult TE for the latest dimensions and design specifications.

*Trademark. TE Connectivity, TE connectivity (logo), and TE (logo) are trademarks. Other logos, product and/or company names may be trademarks of their respective owners.

Table of Contents

1. SCOPE 3

1.1. Related Parts: 3

2. WinTotal-7-End-User-Licence Pictogram 3

2.1. Sequence: 4

© 2019 TE Connectivity Ltd. family of companies.
All Rights Reserved.
| Indicates Change

1. SCOPE

The aim of this document is to provide a descriptive comment for the install guide leaflet supplied in WinTotal v7[1] boxes.

1.1. Related Parts:

1-2186546-1 WinTotal-7-End-User-Licence

2. WinTotal-7-End-User-Licence PICTOGRAM



Figure 1 - WinTotal-7-End-User-Licence leaflet pictograph

[1] And all future versions.

© 2019 TE Connectivity Ltd. family of companies.
All Rights Reserved.
| Indicates Change

2.1. Sequence:



Figure 2 - Web address for download file



Figure 3 - Extract file to folder



Figure 4 - Run executable and install software following on screen prompts

© 2019 TE Connectivity Ltd. family of companies.
All Rights Reserved.
| Indicates Change



Figure 5 - On host PC run software and complete Registration

To install, the user must have local Administrative rights.

Figure 6 - Import descriptive comment

Each purchased copy of WinTotal entitles the user to 1 License (Please see the Wintotal License Agreement for full details). A License is issued in the form of a Serial Number or Dongle.

Key points of the license agreement with reference to multiple installations are:

1.1 TE Connectivity (TE) grants to LICENSEE a non-transferable, non-exclusive personal license to use the Product, including Upgrades which are freely available from TEC.

1.2 TE agrees that the LICENSEE may copy parts of the Product for back-up purposes and that LICENSEE may install copies of the product onto multiple design computers.

1.3 LICENSEE agrees to purchase from TE a separate licensed copy of the product for installation onto each computer attached to a printer or printers.

1.4 LICENSEE agrees to make no additional copies of any part of the Product and specifically agrees not to distribute any part of the Product to third parties for any reason whatsoever without TE Corporation prior written consent.

1.5 LICENSEE acknowledges that, by virtue of this Agreement, LICENSEE acquires only the right to use the Product and does not acquire any rights of ownership in the Product.

WinTotal can be installed and registered once. WinTotal allows for 2 different computers to be registered using 1 serial number. This is to cover ; upgrades, loss, damaged or replaced computers NOT multiple installations (this is in breach of the License Agreement). Once 2 different computers have been registered no further registration can take place (unless authorised from TE)

For latest WinTotal download visit: te.com/wintotal

For direct download visit: te.com/wintotal-download

SERIAL NUMBER:

11111111111111111111111111111111

Figure 7 - WinTotal-7-End-User-Licence Agreement with Registration Serial Number

© 2019 TE Connectivity Ltd. family of companies.
All Rights Reserved.
| Indicates Change