



The PT8232 delivers position feedback via RS232 serial communication to your data acquisition or controller system. The PT8232 sends a raw 16-bit count from 0000H to FFFFH. Additionally this device can be set to continuously send data or send data only when polled.

As the internal position sensing element is a precision potentiometer, this transducer maintains current accurate position even during power loss and does not need to be reset to a "home" position.

PT8232 Cable Actuated Sensor Industrial • RS232

Absolute Linear Position to 60 inches (1524 mm) Aluminum or Stainless Steel Enclosure Options VLS Option to Prevent Free-Release Damage IP68 / NEMA 6

GENERAL

Full Stroke Ranges Electrical Interface Format Accuracy Repeatability Resolution Measuring Cable Enclosure Material Sensor Potentiometer Cycle Life Max. Retraction Acceleration

ELECTRICAL

Input Voltage Input Current Baud Rate Update Rate

ENVIRONMENTAL

Environmental Suitability Operating Temperature Vibration Weight, Aluminum Enclosure Weight, Stainless Steel Encl. 0-2 to 0-60 inches RS232 HEX see ordering information ± 0.02% full stroke ± 0.003% full stroke stainless steel or thermoplastic powder-painted aluminum or stainless steel plastic-hybrid precision potentiometer see ordering information see ordering information

9...22 VDC 40 mA 9600 (selectable to 38.4K) 32 msec

NEMA 4X/6, IP 67 -40° to 200°F (-40° to 90°C) up to 10 g's to 2000 Hz maximum 3 lbs. max. 6 lbs. max.



Output Signal

I/O Format:



Important! All communications to/from the transducer are in HEX!

User Commands:

	User Command				Sensor Response						
Description	<cmd></cmd>	<b0></b0>	<b1></b1>	<b2></b2>	<cmd></cmd>	<b0></b0>	<b1></b1>	<b2></b2>			
Get Sensor Info	0x05	0x00	0x00	0x00	0x05	version ⁽⁴⁾	date ⁽⁵⁾	date ⁽⁵⁾			
Get Serial Number	0x15	0x00	0x00	0x00	0x15	se	rial number ⁽	3)			
Start Continuous Data	0x25	0x00	0x00	0x00	0x25	0x00	0x00	0x00			
Stop Continuous Data	0x35	0x00	0x00	0x00	0x35	0x00	0x00	0x00			
Get Position Data	0x45	0x00	0x00	0x00	0x45	$CMC^{(1)}$	$CMC^{(1)}$	status ⁽²⁾			

⁽¹⁾CMC - Current Measurement Count (Position)

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable.

The CMC is a 16-bit value that occupies the first two bytes (B_0 and B_1) of the data field. B_0 is the MSB (most significant byte) and B_1 is the LSB (least significant byte).

The CMC starts at 0000H with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at FFFFH. This holds true for all ranges.

(2)Status

The status byte is used as a flag to indicate the validity of the position signal that the internal electronics receives from the potentiometer.

Flags are as follows:

0x00 = GREEN, 0x55 = YELLOW, 0xAA = RED

A "green" flag shows everything OK. A "yellow" or "red" flag indicates that the sensor has either been extended beyond its range or that there is a problem with the potentiometer.

⁽³⁾Serial Number

Each sensor has it's own unique serial number. This information can be retrieved by sending the sensor the "Get Serial Number" command.

The serial number is a 3 byte value from which ranges from 0 to 9999999 (decimal).

(4)Version

This is a single byte value (0-255 decimal) which indicates the currently installed firmware version of the sensor.

(5)_{Date}

This is a 2 byte value showing the date of currently installed firmware. This value ranges from 01011 - 12319 (decimal). Format is MMDDY. While the month and day are expressed as two digit numbers the year is expressed in a single digit only.

Example: 08054 = August 5, 2004

RS232 Controller Board and DIP Switch Location



to gain access to the controller board, remove four Allen-Head Screws and remove rear cover.

Baud Rate

The baud rate can be set using switches **7** & **8** on the 8-pole DIP switch found on the rs232 controller board located inside the transducer.





Outline Drawing:



Ordering Information:

Model Number:





Full Stroke Range:

R_order code:	2	5	10	15		20		25		30		40		50		60
full stroke range, min:	2 in.	5 in.	10 in.	15 in.	:	20 in.	:	25 in.	:	30 in.	:	40 in.	:	50	:	60
accuracy (% of f.s.):	1.00%	1.00%	0.15%	0.15%	:	0.15%	:	0.15%	:	0.15%	:	0.10%	:	0.10%	:	0.10%
potentiometer cycle life*:	2.5 x 10 ⁶	2.5 x 10 ⁶	5 x 10 ⁵	5 x 10 ⁵	:	2.5 x 10 ⁵	2	.5 x 10 ⁵	2	2.5 x 10 ⁵						

*-1 cycle is defined as the travel of the measuring cable from full retraction to full extension and back to full retraction

Enclosure Material:

A order code:	AL	SS	316
	powder-painted aluminum	303 stainless steel	316 stainless steel

Ordering Information (cont.):

Measuring Cable:

B _order code:	N34	S47	S31	V62
cable construction:	Ø.034-inch nylon-coated stainless steel rope	Ø.047-inch bare stainless steel rope	Ø.031-inch bare stainless steel rope	Ø.058-inch PVC jacketed vectra fiber rope
available ranges:	all ranges	5, 15, 20, 25, 30-inch only	40, 50, 60-inch only	thru 30 inches only
general use:	indoor	outdoor, debris, high temperature	outdoor, debris, high temperature	high voltage or magnetic field

Measuring Cable Tension:

	• order code:	T1	T2	Т3
		standard tension	medium tension	high tension
	2, 10-inch:	39 oz.	65 oz.	116 oz.
full stroke range	15-inch:	26 oz.	43 oz.	77 oz.
cable tension	20, 10 11011	20 oz.	33 oz.	60 oz.
specifications	5, 25, 50-inch:	16 oz.	26 oz.	47 oz.
	30, 60-inch:	13 oz.	22 oz.	40 oz.
				tension tolerance: ±50%
		maximum acceleration	maximum acceleration	maximum acceleration
	aluminum enclosure:	15 g	25 g	40 g
stai	nless steel enclosure:	6 g	12 g	18 g

Cable Guide Options:



*note: all ranges up to 25 inches only

Electrical Connection:



VLS Option - Free Release Protection

The patented Celesco Velocity Limiting System (VLS) is an option for PT8000 Series cable extension transducers that limits cable retraction to a safe 40 to 55 inches per second.

The VLS option prevents the measuring cable from ever reaching a damaging velocity during an accidental free release. This option is ideal for mobile applications that require frequent cable disconnection and reconnection. It prevents expensive unscheduled downtime due to accidental cable mishandling or attachment failure.

VLS is NOT available for medium and high cable tension options, stainless steel enclosure, cable bellows or 2, 5 and 15-inch stroke ranges. How To Configure Model Number for VLS Option:

VLS8232	C	- <u>AL</u> -	<u>6</u>	- <u>T1</u> -	0	
	15		N34		CG	M6
	20		S47		SS	C25
	25		S31		BR	
	30		V62			
	40					
	50					
	60					
= available options	* *					
creating VLS model numbe	er (exampl	e):				
1. select PT8232 model		PT	8232	-60-S31-	T1-C	G-M6
2. remove "PT" from the	model n	umber 🕅	8232-	-60-S31-	T1-C	G-M6
3. add "VLS"		VLS +	8232-	-60-S31-	T1-C	G-M6

**Note: please contact factory for a solution to options not supported.

VLS8232-60-S31-T1-CG-M6

NORTH AMERICA

Measurement Specialties, Inc. a TE Connectivity Company

Tel: +1-800-522-6752

customercare.chtw@te.com

te.com/sensorsolutions

Measurement Specialties Inc. a TE Connectivity company

Measurement Specialties, TE Connectivity, TE Connectivity (logo) and Every Connection Counts are trademarks. All other logos, products and/ or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2016 TE Connectivity Ltd. family of companies All Rights Reserved.

4. completed model number !

