

IP68 Hood and Housing Series

Table of contents

1.	INTRO	ODUCT	ION	. 2
2.	SUPP	ORTIN	G DOCUMENTS	. 2
	2.1.	Custor	ner drawings	. 2
	2.2.	Produc	ct specification	. 2
	2.3.	Applica	ation Specification	. 2
	2.4.	Standa	ards	. 2
3.	DESC	RPTIO	N	. 3
	3.1.	Assem	bly product	. 3
	3.2.	Hood a	and housing types	. 4
	3	.2.1.	Central locking	. 4
	3	.2.1.1.	Normal type	. 4
	3	.2.1.2.	Hood _Front side entry	. 5
	3	.2.1.3.	Hood _High construction	. 5
	3	.2.1.4.	Housing _With Gasket	. 6
	3	.2.1.5.	Housing _Surface mounting	. 6
	3	.2.1.6.	Housing _Surface mounting	. 7
	3	.2.1.7.	Hood & Housing _Conductive version	. 7
	3	.2.2.	Opposite angle locking	. 8
	3	.2.2.1.	Normal type	. 8
	3	.2.2.2.	Hood _Front side entry	. 9
	3	.2.2.3.	Hood _Two top entry	. 9
	3	.2.2.4.	Hood _Three top entry	10
	3	.2.2.5.	Hood _Three top entry	10
	3	.2.2.6.	Housing _Surface mounting	11
	3	.2.2.7.	Protection Cover	11
4.	REQL	JIREME	NTS	12
	1.2.	Panel	cut-out	12
5.	ASSE	MBLY		15
6.	STOR	AGE		21



1. INTRODUCTION

This specification contains the regulations for assembly of various IP68 Hood and Housing. The following components are available in this system: Hood and housing: H6BPR/H10BPR/H16BPR/H24BPR.

2. SUPPORTING DOCUMENTS

2.1. Customer drawings

For dimensions and materials of the individual parts, please refer to the relative customer drawings of H6BPR/H10BPR/H16BPR/H24BPR.

2.2. Product specification

The product specifications of the used articles are to be taken into account. The product specification describes the technical data as regulations, temperature range and degree of protection. For further reference, please refer to product spec. 108-137014.

2.3. Application Specification

Connectors shall be assembled as below mentioned application specifications to ensure correct connector assembly.

2.4. Standards

- EN 61984: Connectors Safety requirements and tests
- IEC 60664-1: Insulation coordination for equipment within low-voltage systems (Part 1)
- EN 60529: Degrees of Protection Provided by Enclosures (IP Code)
- EN 60068: Environmental testing



3. DESCRPTION

3.1. Assembly product

The following picture (Figure 1) shows an example of complete assembly product.



Figure: 1

The complete product consists of the following components (see figure 1):

- Cable gland
- Hood
- Pin contact
- Male insert
- Female insert
- Socket contact
- Housing



3.2. Hood and housing types

- 3.2.1. Central locking
- 3.2.1.1. Normal type

Hood:

- HXXBPR-TSHC-PG/M
- ➢ HXXBPR-TGHC- PG/M
- ➢ HXXBPR-TS/GHC- PG/M

Housing:

> HXXBPR-AGC



-

- Hood & housing available for size: H6B,H10B, H16B, H24B
- PG/M Thread-1 optional: Blank, PG16,PG21,PG29,PG36,M20,M25,M32,M40
- PG/M Thread-2 optional: Blank, PG16,PG21,PG29,PG36,M20,M25,M32,M40



3.2.1.2. Hood _Front side entry

> HXXBPR-SGRHC-PG/M



Figure: 3

- Hood available for size, Ex.: H6B
- PG/M Thread-1 optional: Blank, M16
- PG/M Thread-2 optional: Blank, M16

Note: Different hood size has different optional PG/M Thread-X. Refer to drawings for detailed information.

3.2.1.3. Hood _High construction

> HXXBPR H130 -TG/SHC-PG/M



Figure: 4

- Hood available for size, Ex.: H24B
- PG/M Thread-1 optional: Blank, G16,PG21,PG29,PG36,M20,M25,M32,M40,M50
- PG/M Thread-2 optional: Blank, G16,PG21,PG29,PG36,M20,M25,M32,M40,M50



3.2.1.4. Housing _With Gasket

➢ HXXBPR-AGC



Figure: 5

- Housing available for size: H6B, H10B, H16B, H24B
- Gasket available for size: H6B, H10B, H16B, H24B

3.2.1.5. Housing _Surface mounting

HXXBPR-SGRHC-PG/M



Figure: 6

- Housing available for size, Ex.: H6B
- PG/M Thread-1 optional: Blank, PG16,PG21,M16 ,M20,M25



3.2.1.6. Housing _Surface mounting

HXXBPR-AGCT



• Housing available for size, Ex.: H16B

3.2.1.7. Hood & Housing _Conductive version

Seal: Conductive seal



- Hood & Housing available for size, Ex.: H24B
- Conductive seal available for size, Ex: H24B
- PG/M Thread-1 optional: Blank, PG16,PG21,PG29,PG36,M20,M25,M32,M40
- PG/M Thread-2 optional: Blank, PG16,PG21,PG29,PG36,M20,M25,M32,M40



3.2.2. Opposite angle locking

3.2.2.1. Normal type

Hood:

- HXXBPR-TSH-PG/M
- ➢ HXXBPR-TGH- PG/M
- > HXXBPR-TS/GH- PG/M

Housing:

HXXBPR-AG



Figure: 9

- Hood & Housing available for size: H6B,H10B, H16B, H24B
- PG/M Thread-1 optional: Blank, PG16,PG21,PG29,PG36,M20,M25,M32,M40
- PG/M Thread-2 optional: Blank, PG16,PG21,PG29,PG36,M20,M25,M32,M40



3.2.2.2. Hood _Front side entry

HXXBPR-TFH-PG/M



- Hood available for size, Ex: H24B
- PG/M Thread-1 optional: Blank, PG16,PG21,M20,M25
- PG/M Thread-2 optional: Blank, PG16,PG21,M20,M25
- PG/M Thread-3 optional: Blank, PG16, PG21, M20, M25

Note: Different housing size has different optional PG/M Thread-X. Refer to drawings for detailed information.

3.2.2.3. Hood _Two top entry

HXXBPR-TGH-PG/M



Figure: 11

- Hood available for size, Ex.: H10B,H16B,H24B
- PG/M Thread-1 optional: Blank, PG16,PG21,PG29,M20,M25,M32,M40
- PG/M Thread-2 optional: Blank, PG16,PG21,PG29,M20,M25,M32,M40



 \triangleright

3.2.2.4. Hood _Three top entry



Figure: 12

- Hood available for size, Ex.: H24B
- PG/M Thread-1 optional: Blank, PG16,PG21,M20,M25
- PG/M Thread-2 optional: Blank, PG16,PG21,M20,M25
- PG/M Thread-3 optional: Blank, PG16,PG21,M20,M25

Note: Different housing size has different optional PG/M Thread-X. Refer to drawings for detailed information.

3.2.2.5. Hood _Three top entry

HXXBPR-TGH-PG/M



Figure: 13

- Hood available for size, Ex.: H24B
- PG/M Thread-1 optional: Blank, PG16,PG21,M20,M25
- PG/M Thread-2 optional: Blank, PG16,PG21,M20,M25
- PG/M Thread-3 optional: Blank, PG16,PG21,M20,M25



3.2.2.6. Housing _Surface mounting

> HXXBPR-SGRH-PG/M



- Hood available for size, Ex.: H10B
- PG/M Thread-1 optional: Blank, PG16,PG21,PG29,M20,M25,M32

Note: Different housing size has different optional PG/M Thread-X. Refer to drawings for detailed information.

3.2.2.7. Protection Cover

HXXBPR-KDB



• Protection Cover available for size: H6B,H10B, H16B, H24B



4. REQUIREMENTS

1.2. Panel cut-out

For housing types other than surface mounted

More detailed information also can be found from related customer drawings.



Figure: 16

		Dimension(mm)						
Housing	size	А	В	С	d			
					Central locking	Opposite angle locking		
H6B		70	32	35	For M4 screw	For M6 screw	48	
H10B		83	32	35	For M4 screw	For M6 screw	60	
H16B		103	32	35	For M4 screw	For M6 screw	82	
H246B		130	32	35	For M4 screw	For M6 screw	108	



 For surface mounted housings HXXBPR-SGRH-PG/M HXXBPR-SGRHC-PG/M Information also can be found from related customer drawings.



Figure: 17

	Houging		Dimension(mm)				
	Housing size	А	В	d			
				Central locking	Opposite angle locking		
HXXBPR-SGRHC-PG/M	H6B	70	45	For M5 screw	-		
HXXBPR-SGRH-PG/M	H10B	140	60	_	For M8 screw		



For surface mounted housings

HXXBPR-AGCT

Information also can be found from related customer drawings.



Figure: 18

Housing size	Dimension(mm)					
Housing size	А	В	С	d	Е	
H16B	112.5	35	43	For M6 screw	82	



5. ASSEMBLY

Assembly housing

For central locking

Fix housing with 4 x M4 screws. Tightening torque refer to spec of screws, but no less than 2Nm.



For opposite angle locking

Fix housing with 4 x M6 screws. Tightening torque refer to spec of screws, but no less than 4Nm.





For surface mounting locking

• HXXBPR-SGRHC-PG/M

Fix housing with 4 x M5 screws. Tightening torque refer to spec of screws, but no less than 3Nm



Figure: 21

• HXXBPR-SGRH-PG/M

Fix housing with 4 x M8 screws. Tightening torque refer to spec of screws, but no less than 5Nm





HXXBPR-AGCT

Fix housing with 4 x M6 screws. Tightening torque refer to spec of screws, but no less than 4Nm



Assembly female insert into housing
Fix female insert with 4 x M3 screws. Tightening torque refer to spec of female insert.







Figure: 25

Note:

- Refer application spec of female insert separately and before fixing to housing, it should be well prepared.
- Whatever the type of housing or the type of female insert, they have same assembly process here.
- > Assembly male insert into hood

Fix female insert with 4 x M3 screws. Tightening torque refer to spec of male insert.







Figure: 27

Note:

- Refer application spec of male insert separately and before fixing to hood, male insert should be well prepared.
- · Whatever the type of hood or the type of male insert, they have same assembly process here.
- Assembly cable gland with hood

Fix cable gland to hood. Tightening torque refer to spec of cable gland.







Figure: 29

Note:

- · Refer application spec of cable gland separately.
- Whatever the type of hood or the type & size of thread hole, they have same assembly process here.
- Assembly hood with housing

Fix hood to housing with 2 x M6 screws. Tightening torque 4Nm



Note:

Whatever the type of hood & housing, they have same assembly process here.



6. STORAGE

The connectors should be stored in the air ventilation, no corrosive gas, no rain and no snow in the warehouse. Relative humidity: less than 85% RH.



Any conflict is found between this file and customer drawings, customer drawings are preferential. And please contact TE Connectivity related engineer if necessary.

----- End------