

## CABLE ASSEMBLIES

For ease of interfacing our LVDTs and RVDTs with our Electronic Signal Conditioners, or with other devices, we offer a variety of cable assemblies. Our cables are shielded and designed for optimum performance under industrial environments. This brochure contains information on the devices they interface with, and the wire configurations and colors.



# LIST OF CABLE ASSEMBLIES AND USE

Part No.	For Transducer	To connect to	AC/DC LVDT	
04290417-000	HCA, HCI, GCA, R-36AS	LVM-110, LiM-4-20	AC	
	HC-485, GC-485	User's reading device	AO	
04290600-000	HCA, HCI, GCA, R-36AS	HCA, HCI, GCA, R-36AS LDM-1000, PML-1000		
04290595-000 (High Temperature)	HCA, HCI, GCA, R-36AS	LDM-1000, PML-1000 Cable: 200°C (392°F) Connector: 125°C (257°F)	AC	
04290457-000	HCA, HCI, GCA, R-36AS	ATA-2001	AC	
04290133-000	HCA, HCI, GCA, R-36AS	IEM-422	AC	
04290560-000	HCA, HCI, GCA, R-36AS	MP-2000	AC	
04290594-000	MP Series	IEM-422	AC	
04290582-000	LBB with option -001	LVM-110, LiM-4-20	AC	
04290596-000	LBB with option -001	LDM-1000, PML-1000	AC	
04290562-000	LBB with option -001	MP-2000	AC	
04290577-000	LBB with option -001	ATA-2001	AC	
04290565-000	LBB with option -004	ATA-2001	AC	
04290552-000	HCD, GCD, HCT, GCT	User's reading device	DC	
04290583-000	HCD, GCD, HCT, GCT	User's reading device	DC	
04290579-000	HCD, GCD, HCT, GCT	Extension cable	DC	
04290589-000	GCD-SE	User's reading device	DC	

Note: Cables are 10 foot long. Contact the factory for different lengths made to order.

# WIRING INFORMATION FOR CABLES WITH STRIPPED AND TINNED LEADWIRE ENDS

### **Shield connections**

The shield drain connections depend on the application. In some cases the shield needs to be connected to an earth connection, usually at only one end of the cable, but some cases would require both.

## Connecting the shield drain wires for AC LVDTs

Shield drain wire should be connected to the electrical ground terminal on the signal conditioner, if available. If worse performance (noise level) is observed after connection, try connecting it to an earth ground. If both results are worse than when not connected, it is acceptable to leave it 'lifted' (not connected).

## Connecting the shield drain wires for DC LVDTs

Connect the shield drain to the common of the power supply. If worse performance is observed after connection, try connecting the drain wire to an earth ground if available. If worse results are observed after connection, leave it 'lifted'.



## Connecting the lead-wires for AC LVDTs:

Part No.	RED	YELLOW	BLACK	BLUE	GREEN	WHITE
04290417-000	Secondary 1	Sec. Center Tap	Secondary 2	Primary		Primary
04290600-000	Pair 1 Primary		Pair 1 Primary			
	Pair 2		Pair 2			
	Secondary 1		Secondary 2			
04290595-000	Secondary 1		Secondary 2		Primary	Primary
04290594-000	Secondary Terminal 3		Secondary Terminal 6		Primary Terminal 1	Primary Terminal 2
	Note: Connect MP Series LVDT Terminals 4 and 5 together (Center Tap)					
04290582-000	Secondary 1		Secondary 2	Primary	Center Tap	Primary
04290596-000	Secondary 1		Secondary 2		Primary	Primary

## Connecting the lead-wires for DC LVDTs:

Part No.	RED	BLACK	GREEN	WHITE
04290552-000	Signal Output	Common	+VDC Supply	-VDC Supply
04290583-000	+VDC Supply	-VDC Supply	Common	Signal Output
04290589-000	+VDC Supply	Supply common	Signal Common	Signal Output

## NORTH AMERICA

Measurement Specialties, Inc., a TE Connectivity Company 1000 Lucas Way Hampton, VA 23666 United States Phone: +1-800-745-8008

Fax: +1-757-766-4297

Email: customercare.hmpt@te.com

### FUROPE

MEAS Deutschland GmbH a TE Connectivity Company Hauert 13 D-44227 Dortmund Germany Phone: +49-(0)231-9740-0

Fax: +49-(0)231-9740-20

Email: <a href="mailto:customercare.dtmd@te.com">customercare.dtmd@te.com</a>

### ASIA

Measurement Specialties China Ltd., a TE Connectivity Company No. 26, Langshan Road High-tech Park (North) Nanshan District, Shenzhen 518057

China Phone: +86-755-33305088

Fax: +86-755-33305099 Email: customercare.shzn@te.com

### te.com/sensorsolutions

Measurement Specialties, Inc., a TE Connectivity company.

Measurement Specialties (MEAS), American Sensor Technologies (AST), TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2016 TE Connectivity Ltd. family of companies All Rights Reserved.