DRAWING NO
AU34711

ITEM	QTY	DESCRIPTION
1	6	NUT-M12-STAIN
2	2	M12 LOWER SCREW
3	2	M12 STUD
4	4	WASHER-M12-FLAT-STAIN
5	2	WASHER-M12-SPRING-STAIN
6	2	CLEAT MOULD TOP
7	2	CLEAT MOULD BOTTOM
8	4	RUBBER INSERT
9	3	CLEAT PLATE
10	2	NUT-BARREL-M12X50
11	1	AU34711- INSTALLATION INSTRUCTION

CLEAT MOULDS SHOULD BE PLACED ONTO ASSEMBLY AS SHOWN ABOVE. THE BOTTOM MOULDING HAS CAVITIES UNDERNEATH TO ACCEPT M12 NUTS

CHECK WASHER

INSTALLATION INSTRUCTION:

KIT SUPPLIED IN DIFFERENT ORDER TO FINAL ASSEMBLY LAYOUT. USE THIS GUIDE AS THE FINAL ASSEMBLY LAYOUT.

1. REMOVE BOTTOM CLEAT BASE FROM ASSEMBLY AND MOUNT TO CHANNEL USING BARREL NUTS AND TIGHTEN TO 30Nm (22.1 ft lb). DO NOT DISASSEMBLE ITEMS 1 & 2.

2. ENSURING RUBBER INSERT IS IN PLACE PUT CABLE ONTO CLAMP AND THREAD STUD INTO TOP OF BARREL NUT UNTIL IT CONTACTS THE LOWER MOUNTING BOLT.

3. SLIDE TOP CLEAT WITH RUBBER INSERT AND ONE STAINLESS STEEL PLATE ONTO STUDS AND SECURE WITH 2 M12 NUTS TIGHTENED TO 15-20Nm (11-14.7 ft lb) ALTERNATING BETWEEN SIDES.

4. SLIDE BOTTOM CLEAT WITH RUBBER INSERT OVER STUDS AND PLACE CABLE.

5. SLIDE TOP CLEAT WITH RUBBER INSERT, STAINLESS STEEL PLATE FLAT WASHERS AND SPRING WASHERS ONTO STUDS AND SECURE WITH 2 M12 NUTS TIGHTENED TO 15-20Nm (11-14.7 ft lb) ALTERNATING BETWEEN SIDES.

CATALOGUE NUMBER	TCPN	CABLE Ø
CC50-60-PL-M12-DOUB	EF8413-000	Ø50-60 (2-2.4in)
CC60-70-PL-M12-DOUB	EF8415-000	Ø60-70 (2.4-2.75in)
CC68-81-PL-M12-DOUB	CV8203-000	Ø68-81 (2.7-3.1in)
CC80-92-PL-M12-DOUB	EF8417-000	Ø80-92 (3.1-3.6in)
CC92-106-PL-M12-DOUB	EF8419-000	Ø92-106 (3.6-4.2in)