

Description	Material	Finish
Body	Brass	Nickel
Pin	Be Cu	Gold
Insulation	PTFE	N/A
Spacer	PTFE	N/A
Gasket	Si Rubber	N/A
Support	Be Cu	Gold
Heat Shrink	Polyolefin	Black



	REVISIONS		
REV	DESCRIPTION	DATE	APPV
В	Updated footprint and dimensions; Added new title block	2-JUL-12	SAH
С	Updated stripping dimensions; Added dimensions to spacer and support	12-JUN-13	SAH

RECOMMENDED CABLE STRIPPING DIMENSIONS



WARNING: THIS DRAWING CONTAINS PROPRIETARY INFORMATION

THAT IS THE SOLE PROPERTY OF LINX TECHNOLOGIES, AND SHALL BE

CONSMA007-R178 ASSEMBLY INSTRUCTIONS

- 1. Strip cable to recommended dimensions.
- 2. Slip heat shink onto cable.
- Solder support onto the braid.
- 4. Place the spacer onto the center conductor.
- 5. Solder or crimp the pin onto the center conductor.
- Insert the pin, center conductor, spacer and support into the body until the top of the socket is even with the threaded opening in the body.
- 7. Crimp the tail of the body onto the support with a 0.093" hex crimp tool (or one labeled for use with RG-178 cable).
- 8. Use heat shrink to cover crimp.

NOTES: (UNLESS OTHERWISE SPECIFIED)

- 1. ALL DIMENSIONS ARE IN INCHES [mm].
- 2. DIMENSIONS APPLY AFTER FINISHING.
- 3. MANUFACTURE TO BE COMPLIANT WITH EU ROHS DIRECTIVE.
- 4. SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.

TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS connectivity DOCUMENT IS PERMITTED, IN WHOLE OR IN PART, WITHOUT THE TITLE: EXPRESS WRITTEN PERMISSION OF LINX TECHNOLOGIES OR ITS DESIGNATED AGENTS. SMA MALE CABLE END CRIMP MATERIAL: TOLERANCES: PROJECTION: FOR RG-178 CABLE .020 [0.50]-.200 [5.00]= ±.008 [0.20] .200 [5.00]-1.200 [30.00]= ±.016 [0.40] 4.75 [120.0]-4.75 [120.0]=±.024 [0.60] ANGLES: ±1° SIZE ANGLES: ±1° ANGLES: ±1 REV CONSMA007-R178 C FINISH: DRAWN: B.MURPHY DT: 2-JUL-12 **ENGR: S.HOGAN** DT: 2-JUL-12 SCALE: 2:1 DO NOT SCALE DRAWING SHEET 1 OF 1 LDCFDLT A